
STAMPING



Stamping applications using ACCU-LUBB require a two-nozzle applicator. Position the nozzles above and below the workpiece prior to the strip entering the die sets. Surface coating the strip with ACCU-LUBB allows lubricant to be drawn into the punch and die/workpiece interface.

It is possible in some stamping applications to port ACCU-LUBB through the blank holder or stripper plate in order to coat the punch and its shear edges. Contact a factory engineer for ideas and assistance.